



Speedway Shelters Wood Base Foundation Assembly Instructions

Materials and tools needed:



Power Drill & 2" woodscrews (28 ea.)



1.5 inch bolts & Nuts (6 ea.), Washers (12 ea.)



3/4 inch plywood- 2x4 Supports



Separate 2x4s approx.. 20" apart from each other (20" centers)



Attach 2x4s to plwood using 2 inch woodscrews



Finished base - for best results apply a standard patio or deck waterproofing agent / sealer.



Add a Speedway Shelters Diamond Tough rubber floor mat for extra protection from moisture & dust.



Locate 2 each anchor holes on both sides of frame assembly. Mark and drill holes



Secure frame to plywood using 1.5" bolts, washers and nuts



Use same 1.5" bolts, nut, washers to secure anchor plate (2 holes).



Keeps water and dirt away and provides dry/clean interior.



Completed Base for your Speed-Way Shelter!